


## Steering Lock


The steering lock ① is located on the steering stem directly below the headlight. Turn the handlebar all the way to the steering stop, either to the left or right, insert the key into the lock, turn the key 60° to the left and press in. Turn the key back to the original position and remove the key. This locks the steering to help prevent theft.



① Steering lock

## Rear Shock Absorber

Each rear shock absorber ① has five adjustment positions for different types of road or riding conditions. Position I is for light loads and smooth road conditions. Positions II to V progressively increase spring tension for a stiffer rear suspension, and are used when the motorcycle is heavily laden or operated on rough roads.



① Rear shock absorber ② Pin spanner