


Fuel Valve

The fuel tank has its fuel valve ① located under the left side. With the valve set in OFF, fuel supply is cut off.

The valve should be set to this position when the motorcycle is parked.

Turn to ON (straight down) for normal riding (gasoline will flow to the carburetors), or to RES, if it becomes necessary to call on the reserve supply.



Grifo de Combustible

El depósito de combustible está dotado de un grifo de combustible ① situado debajo de su lado izquierdo. Con el grifo colocado en posición OFF, alimentación de combustible estará cortada. El grifo deberá colocarse en esta posición al estacionar la motocicleta.

Colocar el grifo en posición ON (hacia abajo) para la conducción normal (la gasolina circulará hacia el carburador) o en posición RES, si se hace necesario acudir al suministro de la reserva.