


Front Brake Fluid

It is important that proper level of brake fluid be maintained in the reservoir. Remove the cap, washer and diaphragm. Fill with SAE J1703 Brake Fluid up to level mark ① inside the reservoir. Reinstall the diaphragm, washer and cap securely. Replace pads as a set if worn to the red line ② on each pad.

NOTE:

Use only genuine Honda replacement friction pads offered by authorized Honda dealers.



Fluido del freno delantero

Es importante que el fluido sea siempre mantenido al nivel predeterminado en el depósito. Quitar la tapa, arandela y diafragma. Llenar con el Fluido de Freno SAE J1703 hasta la marca de nivel ① que se encuentra en el interior del depósito. Remontar el diafragma, arandela y tapa y fijarlos firmemente.

Reemplazar los cojines todos juntos como un conjunto si encuentran desgastados hasta la línea roja ② puesta en el conjín.

NOTA:

Cuando es necesario efectuar mantenimiento del freno, utilizar los cojines de freno de repuesto genuinos de HONDA.