


# CB600F (U)



SWITCH CONTINUITY

IGNITION SWITCH	TURN SIGNAL SWITCH	IGNITION SWITCH	TURN SIGNAL SWITCH
ON	ON	ON	ON
OFF	OFF	OFF	OFF

IGNITION SWITCH	TURN SIGNAL SWITCH	IGNITION SWITCH	TURN SIGNAL SWITCH
ON	ON	ON	ON
OFF	OFF	OFF	OFF

IGNITION SWITCH	TURN SIGNAL SWITCH	IGNITION SWITCH	TURN SIGNAL SWITCH
ON	ON	ON	ON
OFF	OFF	OFF	OFF

IGNITION SWITCH	TURN SIGNAL SWITCH	IGNITION SWITCH	TURN SIGNAL SWITCH
ON	ON	ON	ON
OFF	OFF	OFF	OFF

B	BLACK	6	GREEN
BL	BLUE	10	LIGHT BLUE
BR	BROWN	11	PINK
CD	RED	12	YELLOW
W	WHITE	13	GRAY

0030Z - MBZ - 65800