

Front/Rear Turn Signal Bulb

▲ WARNING

* **The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.**


CAUTION:

* **Wear clean gloves while replacing the bulb.**

NOTE:

* **Be sure to turn the ignition switch OFF when replacing the bulb.**

1. Remove the three screws (1).
2. Remove the turn signal lens (2).



- (1) Screws
- (2) Turn signal lens