


TOOL KIT

Listed below are the items included in the tool kit

The tool kit ① is contained in the compartment located in the battery holder case under the seat. Minor adjustment and parts replacement can be performed with the tools contained in the kit. Adjustments or repairs which cannot be performed with the tools in the kit should be referred to your HONDA dealer

- Axle wrench: for axle nuts
- 17×19 mm open end wrench
- 10×14 mm open end wrench
- 8×12 mm open end wrench
- 45 mm pin wrench: For adjustment of rear suspension
- Spark plug wrench
- Pliers
- No. 2 screw driver
- No. 3 cross point screw driver
- No. 2 cross point screw driver
- Screw driver grip: for screw driver
- Lever: for screw driver
- Handle: for axle wrench
- Tool bag



① Tool kit