

## Headlight Dimmer Switch

Turn headlight dimmer switch (1) to “LO” for low beam, and “HI” for high beam.

## Turn Signal Switch


To signal a left turn move the switch (2) to the “L” position. To signal a right turn move the switch (2) to the “R” position.

## Horn

Press the button (3) to sound the horn.

## Passing Light Control Switch

When this switch (4) is pressed, the headlight flashes on to signal approaching cars when passing.



## Interruptor conmutador del haz del faro

Coloque el interruptor conmutador del haz del faro (1) en posición “LO” para obtener el haz bajo, y en posición “HI” para el alto.

## Control de señales de direcciones

Coloque el interruptor (2) en la posición “L” para indicar la vuelta a la izquierda, o en la posición “R” para la vuelta a la derecha.

## Bocina

Apriete el botón (3) para tocar el claxon.

## Interruptor de mando de la luz de paso

Al oprimir este interruptor (4), el faro ilumina para dar indicaciones a vehículos o para pasar.