OPERATION

COMPONENTS

Ignition Switch

33

Pa	ge	Page	
1	MOTORCYCLE SAFETY	34	Right Handlebar Controls
1	Safe Riding Rules	35	Left Handlebar Controls
2	Protective Apparel		zert Handredar Controls
3	Modifications	36 FE	ATURES (Not required for operation)
4	Loading and Accessories	36	Steering Lock
		37	Helment Holder
7	PARTS LOCATION	38	Seat
10	Instruments and Indicators	38	Cord hook
		39	Document compartment
15	MAJOR COMPONENTS (Information you		2 soument compartment
	need to operate this motorcycle)	40 OP	ERATION
15	Suspension	40	Pre-ride Inspection
18	Brakes	41	Starting the Engine
22	Clutch	44	Running-in
23	Coolant	45	Riding
25	Fuel	46	Braking
29	Engine Oil	47	Parking
30	Tubeless Tyres	47	Anti-theft Tips
33 I	ESSENTIAL INDIVIDUAL		