

## **BULB REPLACEMENT**

(Refer to the maintenance precautions on page 59).

### **Headlight/Position Light Bulb**

#### **▲ WARNING**

- \* **The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.**

#### **CAUTION:**

- \* **Wear clean gloves while replacing the bulb.**
- \* **Do not put finger prints on the headlight bulb, as they may create hot spots on the bulb and cause it to break.**
- \* **If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.**

#### **NOTE:**

- \* **Be sure to turn the ignition switch OFF when replacing the bulb.**