

ITEM	FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE(1)]							REFER TO PAGE		
			COMES FIRST ↓	x 1,000 km	1	6	12	18	24		30	36
			NOTE	x 1,000 mi	0.6	4	8	12	16		20	24
			MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)							82-87	
	DRIVE CHAIN SLIDER					I		I		I	88	
	BRAKE FLUID	(NOTE 3)			I	I	R	I	I	R	18-21	
	BRAKE PAD WEAR				I	I	I	I	I	I	99	
	BRAKE SYSTEM			I		I		I		I	18-21, 101	
*	BRAKE LIGHT SWITCH					I		I		I	107	
*	HEADLIGHT AIM					I		I		I	-	
	CLUTCH SYSTEM					I		I		I	22	
	CLUTCH FLUID	(NOTE 3)			I	I	R	I	I	R	22	
	SIDE STAND					I		I		I	90	
*	SUSPENSION					I		I		I	89	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	-	
**	WHEELS/TYRES					I		I		I	-	
**	STEERING HEAD BEARINGS			I		I		I		I	-	