

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [ NOTE (1) ]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
				6	12	18	24	30	36		
			I, L EVERY 1,000km (600mi)								101
					I		I		I	107	
		NOTE (3)		I	I	R	I	I	R	34	
				I	I	I	I	I	I	117	
				I		I		I		34, 117	
*					I		I		I	—	
*					I		I		I	—	
				I	I	I	I	I	I	37	
						I		I		109	
*						I		I		108	
*				I		I		I		—	
**						I		I		—	
**				I		I		I		—	