

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
* FUEL LINE					I		I		I		—
* THROTTLE OPERATION					I		I		I		97
* AIR CLEANER		NOTE (2)					R			R	—
SPARK PLUGS				EVERY 12,000 km (8,000 mi) I, EVERY 24,000 km (16,000 mi) R							92
* VALVE CLEARANCE							I				—
ENGINE OIL				R		R		R		R	88
ENGINE OIL FILTER				R		R		R		R	89
* ENGINE IDLE SPEED				I	I	I	I	I	I	I	98
RADIATOR COOLANT		NOTE (3)				I		I		R	39
* COOLING SYSTEM						I		I		I	—
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—