

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [ NOTE (1) ]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
	DRIVE CHAIN		I, L EVERY 1,000km (600mi)								97
	DRIVE CHAIN SLIDER				I			I		I	103
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R	29
	BRAKE PAD WEAR				I	I	I	I	I	I	112
	BRAKE SYSTEM			I		I		I		I	29, 112
*	BRAKE LIGHT SWITCH					I		I		I	—
*	HEADLIGHT AIM					I		I		I	—
	CLUTCH SYSTEM			I	I	I	I	I	I	I	32
	SIDE STAND					I		I		I	105
*	SUSPENSION					I		I		I	104
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—
**	WHEELS/TYRES					I		I		I	—
**	STEERING HEAD BEARINGS			I		I		I		I	—