

<b>(Ref.No.) Description</b>	<b>Function</b>
(11) Multi-function display	The display includes the following functions; This display shows the initial display (page 18 ).
Low oil pressure indicator/Coolant temperature indicator/PGM-FI indicator	Lights the low oil pressure indicator and/or coolant temperature indicator and/or PGM-FI indicator to notify that there is abnormality in engine oil pressure and/or coolant temperature and/or PGM-FI (Programmed Fuel Injection) system when the malfunction indicator (MIL) lights. See page 23 – 25 .
Speedometer	Shows riding speed (page 26 ).
Odometer	Shows accumulated mileage (page 26 ).
Tripmeter	Shows mileage per trip (page 26 ).
Digital clock	Shows hour and minute (page 28 ).