

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Tachometer
- (2) Tachometer red zone
- (3) Fuel indicator
- (4) Coolant temperature meter
- (5) Immobilizer system (HISS) indicator
< Except MX, BR type >
- (6) Right control button
- (7) Left control button
- (8) Multi-function display
- (9) Left turn signal indicator
- (10) Malfunction indicator
- (11) Neutral indicator
- (12) High beam indicator
- (13) Right turn signal indicator

