

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Tachometer
- (2) Tachometer red zone
- (3) Fuel indicator
- (4) Immobilizer system (HISS) indicator
〈 Except MX, BR type 〉
- (5) Coolant Temperature meter
- (6) Right turn signal indicator
- (7) High beam indicator
- (8) Right control button
- (9) Neutral indicator
- (10) Left control button
- (11) Information indicator
- (12) Left turn signal indicator
- (13) Multi - function display

