

EQUIPMENT AND CONTROLS

Control Location

- (1) Fuel cap
- (2) Fuse box
- (3) Horn button
- (4) Turn signal switch
- (5) Passing light switch
- (6) Headlight dimmer switch
- (7) Clutch lever
- (8) Choke lever
- (9) Warning and indicator lights
- (10) Rear view mirrors
- (11) Speedometer
- (12) Voltmeter
- (13) Quartz clock (E, ED, F, G)
- (14) Tachometer
- (15) Front suspension air valve
- (16) Front brake fluid reservoir
- (17) Engine stop switch
- (18) Front brake lever
- (19) Headlight switch
- (20) Throttle grip
- (21) Starter button
- (22) Fairing pocket
- (23) Ignition switch

