

## CONTENTS

MOTORCYCLE TRAFFIC SAFETY . . . . .	8	BRAKING . . . . .	96
SAFE RIDING SUGGESTIONS . . . . .	12	SHUTTING OFF THE ENGINE . . . . .	98
LOADING . . . . .	16	PARKING . . . . .	100
EQUIPMENT AND CONTROLS . . . . .	18	MAINTENANCE SCHEDULE . . . . .	102
Temperature Gauge . . . . .	30	MAINTENANCE . . . . .	114
Fuel Gauge . . . . .	32	Air Cleaner . . . . .	114
Maintenance Indicator . . . . .	34	Belt Case Air Cleaner . . . . .	116
Digital Clock . . . . .	36	Radiator Servicing . . . . .	120
OPERATING INSTRUCTIONS . . . . .	38	Engine Oil Level Check . . . . .	126
Ignition Switch . . . . .	38	Engine Oil Change • Oil Filter	
Headlight Switch . . . . .	40	Screen Cleaning . . . . .	128
Headlight Dimmer Switch . . . . .	42	Transmission Oil Change . . . . .	132
Turn Signal Switch . . . . .	44	Side Stand . . . . .	134
Stator Button . . . . .	46	Spark Plug . . . . .	136
Rear Brake Lock . . . . .	48	Crankcase Breather . . . . .	138
Ignition Switch Light . . . . .	52	Battery . . . . .	140
Steering Lock . . . . .	54	Fuses . . . . .	144
Seat Lock . . . . .	56	Serial Numbers . . . . .	148
Helmet Holder . . . . .	58	Color Label . . . . .	150
Glove Box . . . . .	60	STORAGE GUIDE . . . . .	152
PRE-RIDING INSPECTION . . . . .	62	SPECIFICATIONS . . . . .	158
STARTING THE ENGINE . . . . .	82	NOISE EMISSION . . . . .	166
RIDING THE MOTORCYCLE . . . . .	90	WIRING DIAGRAM	