

## Glove Box

### Opening


To open the glove box (1), insert the ignition key (2) and turn it clockwise.

### Closing

To close the glove box, insert the ignition key and turn it clockwise while pressing forward.

#### **NOTE:**

- Do not stow articles whose weight is in excess of 1.5 kg.
- Do not direct water under pressure against the glove box as water will be forced into the glove box compartment.



---

## Gaveta para Guantes

### Como Abrirla

Para abrir la gaveta para guantes (1), inserte la llave de contacto (2) y gírela en el sentido de las agujas del reloj.

### Para Cerrarla

Para cerrar la gaveta para guantes, inserte la llave de contacto y gírela en el sentido de las agujas del reloj presionando hacia delante.

### **NOTA:**

- No guarde en la gaveta artículos que sobrepasen 1,5 kg.
- No dirija agua bajo presión a la gaveta puesto que el agua entraría en el compartimiento de la misma.