

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (Page 62) at each scheduled maintenance period.

I : Inspect and clean, adjust, lubricate or replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

| ITEM | FREQUENCY | WHICHEVER COMES FIRST ↓ | → | | ODOMETER READING [NOTE (1)] | | | | | | | |
|------------------------------|-----------|----------------------------------|------------|-----|-----------------------------|--------------------------------------|----|----|----|----|---------|------------------|
| | | | x 1,000 km | | 1 | 6 | 12 | 18 | 24 | 30 | 36 | REFER TO PAGE |
| | | | x 1,000 mi | 0.6 | 4 | 8 | 12 | 16 | 20 | 24 | | |
| EVERY | MONTH | | 6 | 12 | 18 | 24 | 30 | 36 | | | | |
| * FUEL LINE | | | | | | | I | | I | | I | — |
| * THROTTLE OPERATION | | | | | | | I | | I | | I | — |
| AIR CLEANER | NOTE (2) | | | | | | | R | | | R | 114 |
| CRANKCASE BREATHER | NOTE (3) | | | | | C | C | C | C | C | C | 138 |
| SPARK PLUG | | | | | | I | R | I | R | I | R | 136 |
| * VALVE CLEARANCE | | | | | I | | I | | I | | I | — |
| ENGINE OIL | | | | | R | Replace every 3,000 km (2,000 mi) | | | | | 66, 126 | |
| * ENGINE OIL STRAINER SCREEN | | | | | | | C | | C | | C | 128 |
| * CARBURETOR IDLE SPEED | | | | | I | I | I | I | I | I | I | — |
| RADIATOR COOLANT | NOTE (4) | | | | | | I | | I | | I | 120 |
| * COOLING SYSTEM | | | | | | | I | | I | | I | — |
| * DRIVE BELT | | | | | | | I | R | I | I | R | — |
| BELT CASE AIR CLEANER | | | | | | C | C | C | C | C | C | 116 |