

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	MONTH	INITIAL MAINT.	REGULAR MAINT. INTERVAL				REFER TO PAGE
				km	1,000	2,000	3,000	4,000	
				mi	600	1,200	1,800	2,400	
				1	6	12	18	24	
	DRIVE CHAIN	NOTE (1)		I, L	Every 500 km (300 mi) or every 3 months: I, L				69
	DRIVE CHAIN SLIDER				I	I	I	I	70
	BRAKE FLUID	NOTE (2)			I	I	I	I	15
	BRAKE SHOE/PAD WEAR				I	I	I	I	80, 81
	BRAKE SYSTEM			I	I	I	I	I	15, 80, 81
	CLUTCH SYSTEM			I	I	I	I	I	19
	SIDE STAND					I		I	88
*	SUSPENSION					I		I	86, 87
*	SPARK ARRESTER				Every 1,600 km (1,000 mi) or every 100 operating hours: C				68
*	NUTS, BOLTS, FASTENERS			I		I		I	-
**	WHEELS/TYRES			I	I	I	I	I	26, 76
**	STEERING HEAD BEARINGS			I		I		I	-