


# Brakes

---

## LEFT FRONT



(2) adjusting nut  
(3) brake arm pin

(+) increase freeplay  
(-) decrease freeplay

### Adjustment

1. Turn the front brake adjusting nut (2). Make sure the cut-out on the adjusting nut is seated on the brake arm pin (3).
2. Apply the brake, release it, then spin the wheel and check that it rotates freely. Repeat this procedure several times.
3. Check the freeplay. If you cannot adjust the freeplay properly, see your Honda dealer.