## **Maintenance Schedule**

	Frequency		Frequency	Whichever Comes First		Initial Maint.	Regular Maint. Interval				Refer
			1104	⇒	mi	100	600	1,200	1,800	2,400	to
Ite	ms				km	150	1,000	2,000	3,000	4,000	page:
				Note	Month	1	6	12	18	24	
EMISSION RELATED ITEMS	*	Fuel Line						I		I	
	*	Throttle Operation						I		I	69
		Air Cleaner		Note 1			C	C	C	C	66
		Spark Plug					I	I	I	I	78
	*	Valve Clearance				I	I	I	I	I	74
		Engine Oil				R	R	R	R	R	60
	* *	Engine Oil Strainer Screen						C		C	
	* *	Engine Oil Centrifugal Filter						C		C	
	* *	Engine Idle Speed				I	I	I	I	I	77

Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 146).
In the interest of safety, we recommend these items be serviced only by your Honda dealer.