


Refer to *Safety Precautions* on page 43.


Front Brake Lever Freeplay

RIGHT
SIDE



(1) front brake lever
(2) dust cover

RIGHT
SIDE



(3) lock nut (+) increase freeplay
(4) front brake cable adjuster (-) decrease freeplay

Inspection

Check freeplay by pulling in slowly on the front brake lever (1) until the brake starts to engage.

Freeplay: 13/16 – 1 3/16 in (20 – 30 mm)

If necessary, adjust to the specified range.

Upper Adjustment

1. Pull the rubber dust cover (2) back.
2. Loosen the lock nut (3) and turn the front brake cable adjuster (4).
3. Tighten the lock nut. Return the dust cover to its normal position.
4. Apply the brake, release it, then spin the wheel and check that it rotates freely. Repeat this procedure several times.

(cont'd)