

## Ignition Switch

The ignition switch operates the electrical circuits.

Do not touch the switch whilst riding.

Turning the ignition switch to “OFF” or “LOCK” will prevent the engine from starting.




### Advice

- The headlamp turns “ON” when the engine is started.



### Tips

- Lock the handlebars and pull the key out whenever you leave the vehicle.



Key position	Function	Remove Key
ON (With Engine Running)	Start, day/night ops <ul style="list-style-type: none"><li>• Headlamp “ON”</li><li>• Able to use turn signals, horns, and stops lamps.</li></ul>	Unable
OFF	Stop <ul style="list-style-type: none"><li>• All electrical systems disabled</li></ul>	Yes
LOCK	Handlebar lock engaged <ul style="list-style-type: none"><li>• All electrical systems disabled</li></ul>	YES