


Major free play adjustments are made with the upper adjuster (2) (such as after replacing the throttle cable or removing the carburetor). To adjust free play, loosen the lock nut (1) and turn the adjuster (2). Tighten the lock nut after making the adjustment.

Minor free play adjustments are made with the lower adjuster (3). To adjust free play, remove the rubber cap (4) and turn the adjuster (3).



(3) Rubber cap

(4) Lower Adjuster