


■ MECHANICAL CONTROLS


● FRONT AND REAR BRAKE LEVERS

The front brake lever ① is located at the right handle bar grip and rear brake lever ② is at the left handle bar grip.

Also, the rear brake pedal is located at the right foot rest.



① Front brake lever



② Rear brake lever