

6. After the engine starts operate for 2~3 minutes at medium speed to warm up the engine.
7. When the engine is warm, place the choke lever in the open position.

● **STARTING IN EXTREME COLD WEATHER**

Prime the engine before starting by cranking the engine several times with the ignition switch "OFF". The choke should be fully closed and the throttle opened. Follow with the procedure for starting a cold engine.

● **STARTING A WARM ENGINE**

When the engine is to be restarted while it is still warm proceed as for a cold engine, however, the use of the choke is not necessary.