

Audio System *(Continued)*

To pair a *Bluetooth*[®] sound device

- 1 Select the audio mode 1 or 3 using the **MODE** button. **➡ P.50**
 - ▶ The beep signal cannot be heard when the mode 2 or 4 is chosen.
- 2 Press and hold the **MODE** and **VOLUME** \triangle (up) buttons. The *Bluetooth*[®] device status icon (*Bluetooth*[®] mark and right arrow) starts blinking and the short beep begins to sound. The motorcycle is in pairing mode. (The audio system sends PIN code "0000".)
 - ▶ The PIN code cannot be changed.
- 3 Register a sound device according to its manual.

Registration is completed, blink of the icon will stop and the long beep (1 second) will sound.

 - ▶ If a sound device cannot be registered, the short beep sounds three times and the display returns to the ordinary display.



To end the pairing mode on the way, press and hold the **MODE** and **VOLUME** \triangle (up) buttons.

After pairing, when the audio mode 2 or 4 is selected with the registered sound device in connectable state, the sound device will be connected automatically.

Presence of a *Bluetooth*[®] device in the vicinity sometimes affects the pairing. Some *Bluetooth*[®] sound devices may not be compatible.

In the following cases, registration will be canceled.

- An another sound device is registered.
- The audio system is reset. **➡ P.54**