


To play a track


- 1 Make sure that your audio device is on and connected to the audio system.

▶ The *Bluetooth*[®] device status icon (*Bluetooth*[®] mark and left arrow) is displayed when an audio device is connected.

- 2 Select the audio mode 1 or 2 using the **MODE** button.  P.50

A track will be played and the playing status icon will be displayed when the information of the audio device is received.

▶ If it takes a long time before a track starts playing, check the status of the audio device.



To stop the track

Press the **AUDIO** power button. The audio system turns off and the track stops.

To change a track

Press the **TRACK** \triangle (up) button to skip to the next track.

Press the **TRACK** ∇ (down) button to go back to the beginning of the current or previous track.

Album selection, play mode (Repeat, shuffle, etc.) change and other operations cannot be performed on the audio system. Set up those functions in each audio device to connect in advance.