

ITEM	FREQUENCY	WHICHEVER COMES FIRST	ODOMETER READING				NOTE(1)	
			1,000 km	1	4	8	12	REFER TO PAGE
			1,000 mi	0.6	2.5	5	7.5	
NOTE	MONTHS		6	12	18			
DRIVE CHAIN		NOTE(4)	EVERY 1,000 km(600 mi):LL				70-75	
DRIVE CHAIN SLIDER				I	I	I	76	
BATTERY				I	I	I	85-88	
BRAKE FLUID		NOTE(5)		I	I	I	15-16	
BRAKE SHOE/PAD WEAR				I	I	I	83-84	
BRAKE SYSTEM			I	I	I	I	15, 83-84	
* BRAKE LIGHT SWITCH				I	I	I	91	
* HEADLIGHT AIM				I	I	I	39	
CLUTCH SYSTEM			I	I	I	I	19-20	
SIDE STAND				I	I	I	78	
* SUSPENSION				I	I	I	77	
* NUTS, BOLTS, FASTENERS		NOTE(4)	I		I		-	
** WHEELS/TYRES		NOTE(4)	I	I	I	I	28-32	
** STEERING HEAD BEARINGS			I			I	-	