

## MAINTENANCE

When service is required, remember that your Honda dealer knows your motorcycle best and is fully equipped to provide regular service.

The mileage intervals shown in the MAINTENANCE SCHEDULE are intended as a guide for regular maintenance. Sustained severe or high speed operation will necessitate more frequent servicing. Consult your authorized Honda dealer for recommendations applicable to your individual “needs” or use pattern. If your motorcycle is overturned or involved in a collision, have your Honda dealer inspect the major components: frame, suspension and steering parts, for misalignment or damage.

### **WARNING**

- \* *Stop the engine and support the motorcycle securely on a level surface before performing any maintenance.*
- \* *Use genuine HONDA parts or their equivalent for service repair. The use of replacement parts which are not of equivalent quality may impair the operation of your motorcycle.*

### **NOTE**

- \* To minimize maintenance, a capacitive discharge ignition (CDI) is installed and adjusted at the factory. No adjustment is possible.