

MAINTENANCE

Page

60	MAINTENANCE
61	Maintenance Schedule
64	Tool kit
65	Serial Numbers
66	Colour Label
66	Maintenance Precautions
67	Air Cleaner
69	Belt Case Air Cleaner
72	Crankcase Breather
73	Engine Oil
76	Spark Plug
78	Idle Speed
79	Side Stand
80	Brake Pad Wear
81	Brake Shoe Wear
82	Battery
84	Fuse Replacement
87	Bulb Replacement

page

94	TRANSPORTING
95	CLEANING
98	STORAGE GUIDE
98	Storage
100	Removal from Storage
101	SPECIFICATIONS
105	NOISE WARNING