SERIAL NUMBERS


The frame and engine serial numbers are required when registering your scooter. They may also be required by your dealer when ordering replacement parts.

Record the numbers here for your reference.

The frame number (1) is stamped on the right side of the frame body.


The engine number (2) is stamped on the left side of the crankcase near the rear wheel.

FRAME NO._____



(1) Frame number





(2) Engine number