

(Ref.No.) Description	Function
(9) RESET button	<p>This button is used to reset the tripmeter (page 24) or to adjust the time (page 25).</p> <p>This button is also used to flash the immobilizer system (HISS) indicator when the ignition switch is OFF (page 50).</p>
(10) MODE button	<p>The button is used to select the tripmeter A, the tripmeter B, or the odometer (page 24).</p> <p>This button is also used to adjust the time (page 25).</p>
(11) High beam indicator (blue)	<p>Lights when the headlight is on high beam.</p>
(12) V-matic indicator (amber)	<p>Lights when the V-matic parts have to be replaced. Should also light for a few seconds and then go off when the ignition switch is turned ON.</p> <p>When this indicator lights, contact your Honda dealer.</p>