

5. Tyres – check condition and pressure (pages 40 – 45 ).
6. Throttle – check for smooth opening and full closing in all steering positions.
7. Lights and horn – check that headlight, stop/tail light, turn signals, indicators and horn function properly.
8. Engine stop switch – check for proper function (page 52 ).
9. Side stand ignition cut-off system – check for proper function (page 111 ).