

Brake lever and Parking brake

The single disc brake on the rear axle is cable operated. The parking brake ① should be used when starting the engine and parking the vehicle.

Use the parking brake as an emergency brake when the main brake ② is not operating.

WARNING

Before starting the engine, ensure that the parking brake lever is set.

Release the parking brake lever before driving the ODYSSEY.

Failure to properly set the brake may result in a sudden forward movement when the engine starts.



Levier du frein et frein de stationnement

Le frein à un seul disque sur l'arbre de roue est actionné par un câble. Le frein de stationnement ① devrait être utilisé en faisant démarrer le moteur et en stationnant le véhicule.

Se servir du frein de stationnement comme frein de secours lorsque le frein principal ② ne fonctionne pas.

AVERTISSEMENT

Avant le démarrage du moteur, s'assurer que le levier du frein de stationnement soit en prise.

Relâcher le levier du frein de stationnement avant de conduire l'ODYSSEY.

A défaut de mettre le frein correctement en prise, il peut s'ensuivre un mouvement brusque vers l'avant au moment du démarrage du moteur.

