

## Fuel gauge

The fuel gauge is built into the top compartment cover. The fuel tank capacity is 19ℓ (5.0 U.S. gal., 4.2 Imp. gal.).

When the needle indicates E (empty), a useable reserve of about 3ℓ (0.8 U.S. gal., 0.7 Imp. gal.) remains in the tank. Use low-lead gasoline with a Octane number of 91 or higher. If this is not available, leaded regular gasoline can be used.



## Indicador de nivel de combustible

El indicador de nivel de combustible está incorporado dentro de la cubierta del compartimiento superior. La capacidad del depósito de combustible es de 19 lit. Cuando la aguja indica E (vacío), una reserva del combustible de unos 3 lit. todavía se queda en el depósito. Utilice la gasolina de poco tenor de plomo con el índice octánico de 91 o superior. Si esta gasolina no está disponible, se puede utilizar la gasolina emplomada corriente.