


Instruments



- ① Speedometer
- ② Tachometer
- ③ Odometer
- ④ Tripmeter
- ⑤ Tripmeter reset knob
- ⑥ Tachometer red zone
- ⑦ Water temperature gauge

- **Speedometer:**

Indicates driving speed.

- **Tachometer:**

Indicates engine rpm.

- **Tachometer red zone:**

During acceleration, engine RPM indicator needle may be allowed to briefly enter the red zone. However, the motorcycle must not be operated in the red zone for any length of time and must NEVER be operated beyond it.

- **Odometer:**

Indicates total accumulated distance traveled.

- **Tripmeter:**

Indicates distance traveled per trip. Meter can be reset for each trip.

Reset the tripmeter to zero by turning the tripmeter reset knob in the direction of the arrow.