

## Headlight Dimmer Switch

The headlight, taillight, instrument lights, and running lights (combined in the front turn signal lights) will be illuminated when the ignition switch is turned to the "ON" position.

The headlight dimmer switch ① is located on the left handlebar grip switch housing. When the headlight dimmer switch is moved to the "Hi" position, the high beam is on. When the headlight dimmer switch is moved to the "Lo" position, the low beam is on.


## Horn Button

The horn button ② is located on the left handlebar grip switch housing. When the horn button is pressed the horn will sound.

## Turn Signal Switch

The turn signal switch ③ is located on the left handlebar grip switch housing. It can be operated without taking the hand off the handle grip.

Move the turn signal switch ③ to the "L" position when making a left turn and to the "R" position when making a right turn.



- ① Headlight dimmer switch
- ② Horn button
- ③ Turn signal switch