

**WARNING:**

- Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power at night or in traffic.
- Do not pry the clips open to get a fuse out; you could bend them and cause poor contact with the new fuse. A loose fuse could cause damage to the electrical system and even start a fire.

**CAUTION:** Turn the ignition switch and motorcycle radio switch OFF before checking or replacing the fuse to prevent accidental short-circuiting.

---

**ATENCION:**

- Nunca use fusibles con un valor diferente al especificado. Puede provocar un daño serio al sistema eléctrico o fuego en el mismo, causando una pérdida peligrosa de luces o corriente del motor durante la noche o en el tráfico.
- No abra las grapas a la fuerza para retirar un fusible, ya que puede doblarlas y provocar un mal contacto con el nuevo fusible. Un fusible suelto puede dañar el sistema eléctrico e incluso provocar un fuego.

**PRECAUCION:** Coloque el interruptor de encendido y de la radio de la motocicleta en OFF antes de comprobar o cambiar el fusible para evitar un posible cortocircuito.