

### Trunk inner case:

The trunk inner case (1) is located on the inside of the travel trunk lid.

### Vanity Mirror:


The vanity mirror (2) is located on the trunk case cover.

### Trunk side pockets:

The side pockets (3) are located on both sides of the trunk. Unzip the fasteners to open.

### NOTE:

- The side pockets are for lightweight items. Do not carry more than 0.5 kg (1 lbs) in each side pocket.
- Do not put sharp or hard objects in the side pockets, as these objects may interfere with the opening of the travel trunk lid or may damage the side pockets.



### Caja interior del portaequipajes:

La caja interior del portaequipajes (1) está situada en el interior de la tapa del portaequipajes.

### Espejo:

El espejo (2) está situado en la tapa de la caja del portaequipajes.

### Bolsillos laterales del portaequipajes:

Los bolsillos laterales (3) están situados a ambos lados del portaequipajes. Tire de la cremallera para abrirlos.

### NOTA:

- Los bolsillos laterales son para objetos ligeros. No cargue más de 0,5 kg en cada bolsillo.
- No coloque objetos puntiagudos o duros en los mismos que puedan impedir la apertura de la tapa del portaequipajes o que puedan dañar los bolsillos laterales.

