

NOTE: Torque the following nut and bolts in this order to:

Axle nut: 85–105 N·m (8.5–10.5 kg·m, 61–76 ft·lb)

Shock absorber bolt (Right side): 20–25 N·m (2.0–2.5 kg·m, 14–18 ft·lb)

Shock absorber bolt (Left side): 65–75 N·m (6.5–7.5 kg·m, 47–54 ft·lb)

Axle holding bolt: 24–29 N·m (2.4–2.9 kg·m, 17–21 ft·lb)

NOTA: Apretar las siguientes tuercas y pernos, en este orden, a:

Tuerca del eje: 85–105 N·m (8,5–10,5 kg·m)

Perno del amortiguador (lado derecho): 65–25 N·m (2–2,5 kg·m)

Perno del amortiguador (lado izquierdo): 65–75 N·m (6,5–7,5 kg·m)

Perno de sujeción del eje: 24–29 N·m (2,4–2,9 kg·m)