


FEATURES (Not required for operation)

STEERING LOCK

To lock the steering, turn the handlebars all the way to the left or right, turn the key to P or LOCK while pushing in. Remove the key.

⚠ WARNING

- ***Do not turn the key to P or LOCK while riding the motorcycle; loss of vehicle control may result.***



HELMET HOLDERS

Helmet holders are located below the travel trunk. Open the travel trunk (page 45) and turn the knob in the trunk, the helmet holders will be unlocked.

Hang your helmet on the holder pin and push the pin in to lock it.

⚠ WARNING

- ***The helmet holder is designed for helmet security while parked. Do not ride with a helmet attached to the holder; the helmet may interfere with safe operation and result in loss of control.***

