

AUDIO SYSTEM COVER

To open the audio system cover:

Insert the ignition key and turn it clockwise to open the fuel filler compartment. Push the lock lever to remove the cover.

To lock the cover, insert the tabs in the grooves of the body and push down the cover. Make sure the cover is locked.



Protection Against Water

The audio system is designed to be weatherproof. However, it is not designed to be waterproof if sprayed directly with a hose.

CAUTION:

- *When washing the motorcycle, avoid spraying high pressure water (typical in coin-operated car washes) near the audio system.*