

---

To open the trunk:

Push and hold the trunk release button for approximately one second.

