




### ***AF Lever***

To turn the AF on—push the AF lever up, “AF” will light in the display.

To turn the AF off—push and hold the AF lever up.



In some countries, you cannot utilize features provided by RDS as the RDS function is not provided in all stations.

### ***Program Service Name Indicator***

If the station you are listening to is an RDS station, the frequency display will disappear and the station name information will be displayed.

