

	INITIAL SERVICE PERIOD	REGULAR SERVICE PERIOD	
	1 month	6 months	12 months
FUEL FILTER SCREEN—Clean		○	
*BRAKE SHOES—Inspect, and replace if worn.			○
BRAKE CONTROL LINKAGE— Check linkage and adjust free play if necessary.	●	○	
DRIVE CHAIN AND SPROCKET— Check, lubricate, and adjust if necessary.	●	○	
*WHEEL RIMS AND SPOKES— Check. Tighten spokes and true wheels, if necessary.	●	○	
*CYLINDER, CYLINDER HEAD, PISTON AND MUFFLER— Clean			○
TRANSMISSION OIL—Change	●		○
POLYURETHANE FOAM AIR CLEANER ELEMENT— Clean and oil		○	
ALL NUTS, BOLTS, AND OTHER FASTENERS— Check security and tighten if necessary	●	○	

CAUTION: To maintain the safety and reliability of your HONDA motorcycle do not modify the motorcycle and use only genuine HONDA parts when servicing or repairing.