

CONTENTS

SERIAL NUMBER LOCATION	5
CONTROL LOCATION	6
GASOLINE AND OIL	9
Engine Oil	9
Gasoline	11
Transmission Oil Recommendation	12
OPERATING INSTRUCTIONS	13
Main Switch	13
Ignition Switch	14
Headlight Switch	14
Headlight Dimmer Switch	15
Turn Signal Switch	15
Horn Button	15
Instruments and Indicator Lights	16
Seat Lock and Helmet Holder	18
Steering Lock	18
Fuel Valve	19
Front Forks	20
Rear Shock Absorber	21
PRE-RIDING INSPECTION	22