

# Cargo Bed Controls

## Tilt Bed Levers

Before raising the cargo bed, select a firm level surface and set the parking brake.

Your Honda MUV has both tilt bed levers, one on each side of the vehicle just under the front of the bed. Using either lever, the front end of the bed will lift up. Making it easier to dump items out the rear or to maintain the air cleaner, lubricate the cargo bed pivots and cargo bed strikers.

To raise the front of the cargo bed, first make sure that the tailgate has been unlatched and lowered, then pull up on either lever.

1. Pull up the tilt bed lever on each side, then grasp the top of the bed rail.
2. Raise the front end of the cargo bed.

Do not drive the Honda MUV with the front end of the cargo bed raised.

**SLOWLY LIFT UP  
THE CARGO BED.**

